

Implementing a C-887 PI Controller in TwinCAT 3.1 for Motion and Activation of new Coordinate Systems

For more information on TwinCAT MC2 libraries refer to the Beckhoff Information System (http://infosys.beckhoff.com/content/1033/tcplclib_tc2_mc2/index.html?id=4786081293094367280).

EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

TwinCAT® is a registered trademark of and licensed by Beckhoff Automation GmbH.

The software products provided by PI are subject to the General Software License Terms of Physik Instrumente (PI) GmbH & Co. KG and may contain and/or use third-party software components. Further information can be found in the [General Software License Terms](#) and in the [Third-Party Software Notes](#) on our website.


The example described in this document can be found in the \Samples\EtherCAT\TwinCAT directory of the PI software CD delivered with your PI controller.

1 Prerequisites

- C-887 controller with PI software CD (in the scope of delivery) and user documentation (short instructions, in the scope of delivery, or user manual, available from our website).
- PI hexapod with user documentation (short instructions, in the scope of delivery, or user manual, available from our website).
- You have installed the C-887 controller and the hexapod according to the installation instructions in the user documentation.
- You have executed test motions of the hexapod according to the instructions in the user documentation of the C-887 controller.
- TwinCAT 3.1 XAE
- You have copied the EtherCAT Device Description file (EDS) for your controller from the \EDS directory of the PI software CD into the TwinCAT IO configuration directory (e.g. "C:\TwinCAT\3.1\Config\Io\EtherCAT").

2 Set Up a new TwinCAT Project and add the Controller

- Start with an empty TwinCAT project.
- Add your EtherCAT master device and adjust its adapter settings.




- To add a PI controller click the Scan button 

Or


- Add the controller manually as a new device (right-click at the EtherCAT master device → Add new item)


User Manual

A000T0075, valid for C-887 controller with EtherCAT interface
FRIE, SSc, BRo, 2/24/2020



- Let TwinCAT automatically append the linked axes to a NC configuration





- Thus the position inputs and outputs of the PI controller modules are mapped automatically to the NC axes.
- For a manual mapping, map the position inputs and outputs of the axis to the corresponding NC axis as follows:

2.1 Position Inputs

Statusword:

MOTION -> NC-Task 1 SAF -> Axes -> Axis X -> Drive -> In -> nState1 and nState2. Do this for each axis.




PLC -> PIHexapodNewCS -> PIHexapodNewCS Instance -> Main.stPIHexapod.nStatusWord

(press and hold Ctrl to select more than one item)

For nState2 set an offset of 8 bits.


User Manual

A000T0075, valid for C-887 controller with EtherCAT interface
FRIE, SSc, BRo, 2/24/2020




Position actual value:

MOTION -> NC-Task 1 SAF -> Axes -> Axis X -> Enc -> In -> nDataIn1. Do this for each axis.



Following error actual value:

MOTION -> NC-Task 1 SAF -> Axes -> Axis X -> Drive -> In -> nDataIn1. Do this for each axis.






2.2 Position Outputs

Controlword:


MOTION -> NC-Task 1 SAF -> Axes -> Axis X -> Drive -> Out -> nCtrl1 and nCtrl2. Do this for each axis.

For nCtrl2 set an offset of 8 bits.



Target Position:

MOTION -> NC-Task 1 SAF -> Axes -> Axis X -> Drive -> Out -> nDataOut1. Do this for each axis.




3 Adjust Axis Parameters

- Now adjust the NC axis parameter configuration as follows:

3.1 Axis Velocity and Acceleration

Adjust the velocity and acceleration according to the documentation of the hexapod. Do this for each axis.




3.2 Encoder Parameter for Axes

Set *Scaling Factor* and *Reference System* of NC axes to suitable values (for details, see controller documentation). Do this for each axis.


User Manual

A000T0075, valid for C-887 controller with EtherCAT interface
FRIE, SSc, BRo, 2/24/2020



4 Create a PLC Project for a Simple PTP Motion

- Create a new standard PLC project.
- Add the following libraries to the references section of the PLC project:
 - IO -> Tc2_EtherCAT
 - Motion -> PTP -> Tc2_MC2
 - Motion -> NCI -> Tc2_NCI
 - Motion -> NCI -> Tc2_PlcInterpolation
 - System -> Tc2_Uilities



- Create a new Data Unit Type (DUT) with the identifier “ST_PiHexapod” as structure and add the following variables:

```

TYPE ST_PiHexapod :
STRUCT
    stX                : AXIS_REF;
    stY                : AXIS_REF;
    stZ                : AXIS_REF;
    stU                : AXIS_REF;
    stV                : AXIS_REF;
    stW                : AXIS_REF;
    nModeOfOperation   AT %Q* : BYTE := 0;
    nModeOfOperationDisplay AT %I* : BYTE := 0;
    nStatusWord        AT %I* : UINT := 0;
    WorkCSPDO          AT %Q* : ARRAY [1..6] OF DINT := [0, 0, 0, 0, 0, 0];
    ToolCSPDO          AT %Q* : ARRAY [1..6] OF DINT := [0, 0, 0, 0, 0, 0];
    bHomed             : BOOL := FALSE;
    bEnabled           : BOOL := FALSE;
END_STRUCT
END_TYPE
    
```

- Copy the following variables to the window for the local variables of the MAIN PLC program:

```

PROGRAM MAIN
VAR
    stPiHexapod          : ST_PiHexapod;
    fbPower              : FB_PowerHexapod;
    fbHome               : FB_HomeHexapod;
    fbSetAndActivateCSHexapod : FB_SetAndActivateCSHexapod;
    fbMove               : FB_MoveHexapod;
    nState               : UDINT := 0;

    (* add "NetID" of EtherCAT Master and "EtherCAT address" of slave device *)
    NetID                : T_AmsNetId := '172.16.56.19.2.1';
    
```

```
SlaveAddr      : UINT := 1001;  
END_VAR
```

- Copy the following code to the MAIN PLC program (error handling has to be extended in the MAIN PLC program and each function block):

```
(* (c) 2017-2019 Physik Instrumente (PI) GmbH & Co. KG  
Software products that are provided by PI are subject to the General Software License  
Agreement of Physik Instrumente (PI) GmbH & Co. KG and may incorporate and/or make use of  
third-party software components.  
For more information, please read the General Software License Agreement and the Third  
Party Software Note linked below.  
General Software License Agreement:  
http://www.physikinstrumente.com/download/EULA\_PhysikInstrumenteGmbH\_Co\_KG.pdf  
Third Party Software Note:  
http://www.physikinstrumente.com/download/TPSWNote\_PhysikInstrumenteGmbH\_Co\_KG.pdf
```

This sample was created with TwinCAT version v3.1.4022.4

PLC-axis parameters in mm, mm/s, mm/s2 and mm/s3
set scaling factor of NC-axes to suitable value (for details see controller documentation)

Sample program to demonstrate:

- homing of hexapod
- configuration of customized coordinate systems
- movement of hexapod axis

Error handling is missing and the sample is not complete to run a machine.

```
*)  
stPIHexapod.stX.ReadStatus();  
stPIHexapod.stY.ReadStatus();  
stPIHexapod.stZ.ReadStatus();  
stPIHexapod.stU.ReadStatus();  
stPIHexapod.stV.ReadStatus();  
stPIHexapod.stW.ReadStatus();
```

CASE nState OF

```
0:  
  (* power on *)  
  fbPower(  
    bEnable:= TRUE,  
    fOvr:= 100.0,  
    stPIHexapod := stPIHexapod );
```

```
  IF stPIHexapod.bEnabled THEN  
    nState := 10;  
  END_IF
```

```
10:  
  (* homing *)  
  fbHome.bExecute:= TRUE;  
  
  IF fbHome.bDone THEN  
    fbHome.bExecute:= FALSE;  
    nState := 20;  
  END_IF
```

```
20:
  (* reset coordinate system *)
  fbSetAndActivateCSHexapod.Work[1] := 0;
  fbSetAndActivateCSHexapod.Work[2] := 0;
  fbSetAndActivateCSHexapod.Work[3] := 0;
  fbSetAndActivateCSHexapod.Work[4] := 0;
  fbSetAndActivateCSHexapod.Work[5] := 0;
  fbSetAndActivateCSHexapod.Work[6] := 0;
  fbSetAndActivateCSHexapod.Tool[1] := 0;
  fbSetAndActivateCSHexapod.Tool[2] := 0;
  fbSetAndActivateCSHexapod.Tool[3] := 0;
  fbSetAndActivateCSHexapod.Tool[4] := 0;
  fbSetAndActivateCSHexapod.Tool[5] := 0;
  fbSetAndActivateCSHexapod.Tool[6] := 0;

  fbSetAndActivateCSHexapod.bExecute := TRUE;
  IF fbSetAndActivateCSHexapod.bDone THEN
    fbSetAndActivateCSHexapod.bExecute := FALSE;
    nState := 30;
  END_IF

30:
  (* move *)
  fbMove.PosX := 5;
  fbMove.bExecute := TRUE;

  IF fbMove.bDone THEN
    fbMove.bExecute := FALSE;
    nState:= 40;
  END_IF

40:
  (* move *)
  fbMove.PosX := 0;
  fbMove.bExecute := TRUE;

  IF fbMove.bDone THEN
    fbMove.bExecute := FALSE;
    nState:= 50;
  END_IF

50:
  (* activate coordinate system *)
  fbSetAndActivateCSHexapod.Work[1] := 0;
  fbSetAndActivateCSHexapod.Work[2] := 0;
  fbSetAndActivateCSHexapod.Work[3] := 0;
  fbSetAndActivateCSHexapod.Work[4] := 0;
  fbSetAndActivateCSHexapod.Work[5] := 0;
  fbSetAndActivateCSHexapod.Work[6] := 90;
  fbSetAndActivateCSHexapod.Tool[1] := 0;
  fbSetAndActivateCSHexapod.Tool[2] := 0;
  fbSetAndActivateCSHexapod.Tool[3] := 0;
  fbSetAndActivateCSHexapod.Tool[4] := 0;
  fbSetAndActivateCSHexapod.Tool[5] := 0;
  fbSetAndActivateCSHexapod.Tool[6] := 90;

  fbSetAndActivateCSHexapod.bExecute := TRUE;
```

```
IF fbSetAndActivateCSHexapod.bDone THEN
    fbSetAndActivateCSHexapod.bExecute := FALSE;
    nState := 60;
END_IF

60:
    (* move *)
    fbMove.PosX := 5;
    fbMove.bExecute := TRUE;

    IF fbMove.bDone THEN
        fbMove.bExecute := FALSE;
        nState:= 70;
    END_IF

70:
    (* move *)
    fbMove.PosX := 0;
    fbMove.bExecute := TRUE;

    IF fbMove.bDone THEN
        fbMove.bExecute := FALSE;
        nState:= 80;
    END_IF

80:
    nState := 20;

END_CASE

fbHome(stPIHexapod := stPIHexapod);
fbMove(stPIHexapod := stPIHexapod);
fbSetAndActivateCSHexapod(stPIHexapod := stPIHexapod, sNetId := NetID, nSlaveAddr :=
SlaveAddr);
```

- Create a new PLC function block (Add -> POU...) named “FB_PowerHexapod” and copy the following variables to its window for the local variables:

```
FUNCTION_BLOCK FB_PowerHexapod
VAR_INPUT
    bEnable    : BOOL := FALSE;
    fOvr       : LREAL;
END_VAR
VAR_OUTPUT
    bError     : BOOL := FALSE;
    nErrorId   : UDINT := 0;
END_VAR
VAR_IN_OUT
    stPIHexapod : ST_PIHexapod;
END_VAR
VAR
    fbPowerX    : MC_Power;
    fbPowerY    : MC_Power;
    fbPowerZ    : MC_Power;
    fbPowerU    : MC_Power;
    fbPowerV    : MC_Power;
    fbPowerW    : MC_Power;
END_VAR
```

- And copy the following code to the “FB_PowerHexapod” function block:

```
(* ToDo: extend error handling *)
(* Enable all six hexapod axes *)

fbPowerX(
  Axis:= stPIHexapod.stX ,
  Enable:= bEnable ,
  Enable_Positive:= bEnable,
  Enable_Negative:= bEnable,
  Override:=fOvr ,
  BufferMode:= ,
  Status=> ,
  Busy=> ,
  Active=> ,
  Error=> ,
  ErrorID=> );

fbPowerY(
  Axis:= stPIHexapod.stY ,
  Enable:= bEnable ,
  Enable_Positive:= bEnable,
  Enable_Negative:= bEnable,
  Override:=fOvr ,
  BufferMode:= ,
  Status=> ,
  Busy=> ,
  Active=> ,
  Error=> ,
  ErrorID=> );

fbPowerZ(
  Axis:= stPIHexapod.stZ ,
  Enable:= bEnable ,
  Enable_Positive:= bEnable,
  Enable_Negative:= bEnable,
  Override:=fOvr ,
  BufferMode:= ,
  Status=> ,
  Busy=> ,
  Active=> ,
  Error=> ,
  ErrorID=> );

fbPowerU(
  Axis:= stPIHexapod.stU ,
  Enable:= bEnable ,
  Enable_Positive:= bEnable,
  Enable_Negative:= bEnable,
  Override:=fOvr ,
  BufferMode:= ,
  Status=> ,
  Busy=> ,
  Active=> ,
  Error=> ,
  ErrorID=> );

fbPowerV(
  Axis:= stPIHexapod.stV ,
  Enable:= bEnable ,
  Enable_Positive:= bEnable,
  Enable_Negative:= bEnable,
```

```
Override:=fOvr ,
BufferMode:= ,
Status=> ,
Busy=> ,
Active=> ,
Error=> ,
ErrorID=> );
fbPowerW(
Axis:= stPIHexapod.stW ,
Enable:= bEnable ,
Enable_Positive:= bEnable,
Enable_Negative:= bEnable,
Override:=fOvr ,
BufferMode:= ,
Status=> ,
Busy=> ,
Active=> ,
Error=> ,
ErrorID=> );

IF fbPowerX.Error THEN
    bError := TRUE;
    nErrorId := fbPowerX.ErrorID;
ELSE
    IF fbPowerX.Status AND fbPowerY.Status AND fbPowerZ.Status AND fbPowerU.Status AND
fbPowerV.Status AND fbPowerW.Status THEN
        stPIHexapod.bEnabled := TRUE;
    ELSE
        stPIHexapod.bEnabled := FALSE;
    END_IF
END_IF
```

- Create a new PLC function block (Add -> POU...) named “FB_HomeHexapod” and copy the following variables to its window for the local variables:

```
FUNCTION_BLOCK FB_HomeHexapod
VAR_INPUT
    bExecute      : BOOL := FALSE;
END_VAR
VAR_OUTPUT
    bBusy         : BOOL := FALSE;
    bDone         : BOOL := FALSE;
    bError        : BOOL := FALSE;
    nErrorId      : UDINT := 0;
END_VAR
VAR_IN_OUT
    stPIHexapod   : ST_PIHexapod;
END_VAR
VAR
    nState        : UDINT := 0;
    fbSetPos      : FB_SetPosHexapod;
END_VAR
```

- And copy the following code to the “FB_HomeHexapod” function block:

```
(*    ToDo: extend error handling    *)

CASE nState OF
```



```
0:
  IF bExecute THEN
    bBusy := TRUE;
    bDone := FALSE;
    nState := 10;
  END_IF
10:
  (* set Mode of Operation to 6 and wait until Mode of Operation Display switches to 6 *)
  stPIHexapod.nModeOfOperation := 6;
  IF stPIHexapod.nModeOfOperationDisplay = 6 THEN
    nState := 20;
  END_IF
20:
  (* wait until homing move is finished *)
  (* Statusword has to be set as 1010000100111 *)
  IF (stPIHexapod.nStatusWord AND 5159) = 5159 THEN
    stPIHexapod.bHomed := TRUE;
    nState := 30;

  END_IF
30:
  (* set hexapod absolute positions to 0 *)
  fbSetPos.PosX := 0.0;
  fbSetPos.PosY := 0.0;
  fbSetPos.PosZ := 0.0;
  fbSetPos.PosU := 0.0;
  fbSetPos.PosV := 0.0;
  fbSetPos.PosW := 0.0;
  fbSetPos.Execute := TRUE;

  IF fbSetPos.bError THEN
    nState := 9999;
  ELSE
    IF (fbSetPos.bDone) THEN
      fbSetPos.Execute := FALSE;
      nState := 40;
    END_IF
  END_IF
40:
  (* set Mode of Operation to 8 and wait until Mode of Operation Display switches to 8 *)
  stPIHexapod.nModeOfOperation := 8;
  IF stPIHexapod.nModeOfOperationDisplay = 8 THEN
    nState := 50;
  END_IF
50:
  bBusy := FALSE;
  IF NOT bExecute THEN
    nState := 0;
    bDone := FALSE;
  ELSE
    bDone := TRUE;
  END_IF
```

```
9999:
    bError := TRUE;
    nErrorId := fbSetPos.nErrorId;

END_CASE

fbSetPos (stPIHexapod := stPIHexapod);
```

- Create a new PLC function block (Add -> POU...) named “FB_MoveHexapod” and copy the following variables to its window for the local variables:

```
FUNCTION_BLOCK FB_MoveHexapod
VAR_IN_OUT
    stPIHexapod      : ST_PIHexapod;
END_VAR
VAR_INPUT
    bExecute          : BOOL := FALSE;
    PosX              : LREAL := 0;
    PosY              : LREAL := 0;
    PosZ              : LREAL := 0;
    PosU              : LREAL := 0;
    PosV              : LREAL := 0;
    PosW              : LREAL := 0 ;

    (* default parameters, please adapt according to hexapod type! *)
    VelX              : LREAL := 1;
    VelY              : LREAL := 1;
    VelZ              : LREAL := 1;
    VelU              : LREAL := 1;
    VelV              : LREAL := 1;
    VelW              : LREAL := 1;
    AccX              : LREAL := 10;
    AccY              : LREAL := 10;
    AccZ              : LREAL := 10;
    AccU              : LREAL := 10;
    AccV              : LREAL := 10;
    AccW              : LREAL := 10;
END_VAR
VAR_OUTPUT
    bBusy             : BOOL := FALSE;
    bDone             : BOOL := FALSE;
    bError            : BOOL := FALSE;
    nErrorId          : UDINT      := 0;
END_VAR
VAR
    fbMovX            : MC_MoveAbsolute;
    fbMovY            : MC_MoveAbsolute;
    fbMovZ            : MC_MoveAbsolute;
    fbMovU            : MC_MoveAbsolute;
    fbMovV            : MC_MoveAbsolute;
    fbMovW            : MC_MoveAbsolute;

    nState            : UDINT      := 0;
END_VAR
```

- And copy the following code to the “FB_MoveHexapod” function block:

```
(* ToDo: extend error handling *)
```

```
CASE nState OF
0:
    IF bExecute THEN
        bBusy := TRUE;
        bDone := FALSE;
        nState := 10;
    END_IF

10:
    IF VelX < 0.1 THEN
        VelX := 1;
    END_IF
    IF AccX < 0.1 THEN
        AccX := 1;
    END_IF
    IF VelY < 0.1 THEN
        VelY := 1;
    END_IF
    IF AccY < 0.1 THEN
        AccY := 1;
    END_IF
    IF VelZ < 0.1 THEN
        VelZ := 1;
    END_IF
    IF AccZ < 0.1 THEN
        AccZ := 1;
    END_IF
    IF VelU < 0.1 THEN
        VelU := 1;
    END_IF
    IF AccU < 0.1 THEN
        AccU := 1;
    END_IF
    IF VelV < 0.1 THEN
        VelV := 1;
    END_IF
    IF AccV < 0.1 THEN
        AccV := 1;
    END_IF
    IF VelW < 0.1 THEN
        VelW := 1;
    END_IF
    IF AccW < 0.1 THEN
        AccW := 1;
    END_IF

    fbMovX.Position:= PosX;
    fbMovX.Velocity:= VelX;
    fbMovX.Acceleration:= AccX;
    fbMovX.Execute:= bExecute;

    fbMovY.Position:= PosY;
    fbMovY.Velocity:= VelY;
    fbMovY.Acceleration:= AccY;
    fbMovY.Execute:= bExecute;

    fbMovZ.Position:= PosZ;
```

```
fbMovZ.Velocity:= VelZ;
fbMovZ.Acceleration:= AccZ;
fbMovZ.Execute:= bExecute;

fbMovU.Position:= PosU;
fbMovU.Velocity:= VelU;
fbMovU.Acceleration:= AccU;
fbMovU.Execute:= bExecute;

fbMovV.Position:= PosV;
fbMovV.Velocity:= VelV;
fbMovV.Acceleration:= AccV;
fbMovV.Execute:= bExecute;

fbMovW.Position:= PosW;
fbMovW.Velocity:= VelW;
fbMovW.Acceleration:= AccW;
fbMovW.Execute:= bExecute;

IF fbMovX.Done AND fbMovY.Done AND fbMovZ.Done AND fbMovU.Done AND fbMovV.Done AND
fbMovW.Done THEN
    fbMovX.Execute:= FALSE;
    fbMovY.Execute:= FALSE;
    fbMovZ.Execute:= FALSE;
    fbMovU.Execute:= FALSE;
    fbMovV.Execute:= FALSE;
    fbMovW.Execute:= FALSE;

    nState := 500;
END_IF

IF fbMovX.Error OR fbMovY.Error OR fbMovZ.Error OR fbMovU.Error OR fbMovV.Error OR
fbMovW.Error THEN
    fbMovX.Execute:= FALSE;
    fbMovY.Execute:= FALSE;
    fbMovZ.Execute:= FALSE;
    fbMovU.Execute:= FALSE;
    fbMovV.Execute:= FALSE;
    fbMovW.Execute:= FALSE;

    nState := 9999;
END_IF

500:
bBusy := FALSE;
IF NOT bExecute THEN
    nState := 0;
    bDone := FALSE;
ELSE
    bDone := TRUE;
END_IF

9999:
(* an error occurred *)
(* error handling is still missing *)
bError      := TRUE;
nErrorId    := fbMovX.ErrorId;
```

```
END_CASE
```

```
fbMovX( Axis:=stPIHexapod.stX );  
fbMovY( Axis:=stPIHexapod.stY );  
fbMovZ( Axis:=stPIHexapod.stZ );  
fbMovU( Axis:=stPIHexapod.stU );  
fbMovV( Axis:=stPIHexapod.stV );  
fbMovW( Axis:=stPIHexapod.stW );
```

- Create a new PLC function block (Add -> POU...) named “FB_SetAndActivateCSHexapod” and copy the following variables to its window for the local variables:

```
FUNCTION_BLOCK FB_SetAndActivateCSHexapod  
VAR_IN_OUT  
    stPIHexapod          : ST_PIHexapod;  
END_VAR  
VAR_INPUT  
    bExecute             : BOOL := FALSE;  
    sNetId               : T_AmsNetId;          (* NetId of EtherCAT Master *)  
    nSlaveAddr           : UINT;                (* Port Number of EtherCAT Slave *)  
    Work                 : ARRAY [1..6] OF LREAL;  
    Tool                 : ARRAY [1..6] OF LREAL;  
END_VAR  
VAR_OUTPUT  
    bBusy                : BOOL := FALSE;  
    bDone                : BOOL := FALSE;  
    bError               : BOOL := FALSE;  
    nErrorId             : UDINT := 0;  
END_VAR  
VAR  
    nState               : UDINT := 0;  
    nHsk                 : DINT := 1;  
    bufferWork           : ARRAY [1..6] OF DINT;  
    bufferTool           : ARRAY [1..6] OF DINT;  
    i                   : INT;  
  
    fbSdoWriteWorkX      : FB_EcCoESdoWrite;  
    fbSdoWriteWorkY      : FB_EcCoESdoWrite;  
    fbSdoWriteWorkZ      : FB_EcCoESdoWrite;  
    fbSdoWriteWorkU      : FB_EcCoESdoWrite;  
    fbSdoWriteWorkV      : FB_EcCoESdoWrite;  
    fbSdoWriteWorkW      : FB_EcCoESdoWrite;  
    fbSdoWriteToolX      : FB_EcCoESdoWrite;  
    fbSdoWriteToolY      : FB_EcCoESdoWrite;  
    fbSdoWriteToolZ      : FB_EcCoESdoWrite;  
    fbSdoWriteToolU      : FB_EcCoESdoWrite;  
    fbSdoWriteToolV      : FB_EcCoESdoWrite;  
    fbSdoWriteToolW      : FB_EcCoESdoWrite;  
    fbSdoWriteHsk        : FB_EcCoESdoWrite;  
  
    fbSetPos             : FB_SetPosHexapod;  
  
    fbTimer1: TON;  
END_VAR
```

- And copy the following code to the “FB_SetAndActivateCSHexapod” function block:

```
(* ToDo: extend error handling *)

CASE nState OF
0:
    IF bExecute THEN
        bBusy := TRUE;
        bDone := FALSE;
        nState := 10;
        fbTimer1 (PT:=T#100MS);
    END_IF

10:
    (* set Mode of Operation to 0 and wait until Mode of Operation Display switches to 0
    *)
    stPIHexapod.nModeOfOperation := 0;
    IF stPIHexapod.nModeOfOperationDisplay = 0 THEN
        nState := 20;
    END_IF

20:
    FOR i := 1 TO 6 DO
        bufferWork[i] := LREAL_TO_DINT(Work[i] * 1000);
        bufferTool[i] := LREAL_TO_DINT(Tool[i] * 1000);
    END_FOR

    nState := 30;

30:
    (* write Work coordinate system to SDOs *)
    fbSdoWriteWorkX(
        sNetId      := sNetId,
        nSlaveAddr   := nSlaveAddr,
        nIndex       := 16#5000,
        nSubIndex    := 1,
        pSrcBuf      := ADR(bufferWork[1]),
        cbBufLen     := SIZEOF(bufferWork[1]),
        bExecute     := bExecute
    );
    fbSdoWriteWorkY(
        sNetId      := sNetId,
        nSlaveAddr   := nSlaveAddr,
        nIndex       := 16#5000,
        nSubIndex    := 2,
        pSrcBuf      := ADR(bufferWork[2]),
        cbBufLen     := SIZEOF(bufferWork[2]),
        bExecute     := bExecute
    );
    fbSdoWriteWorkZ(
        sNetId      := sNetId,
        nSlaveAddr   := nSlaveAddr,
        nIndex       := 16#5000,
        nSubIndex    := 3,
        pSrcBuf      := ADR(bufferWork[3]),
        cbBufLen     := SIZEOF(bufferWork[3]),
        bExecute     := bExecute
    );
```

```
fbSdoWriteWorkU(  
    sNetId      := sNetId,  
    nSlaveAddr  := nSlaveAddr,  
    nIndex      := 16#5000,  
    nSubIndex   := 4,  
    pSrcBuf     := ADR(bufferWork[4]),  
    cbBufLen    := SIZEOF(bufferWork[4]),  
    bExecute    := bExecute  
);  
fbSdoWriteWorkV(  
    sNetId      := sNetId,  
    nSlaveAddr  := nSlaveAddr,  
    nIndex      := 16#5000,  
    nSubIndex   := 5,  
    pSrcBuf     := ADR(bufferWork[5]),  
    cbBufLen    := SIZEOF(bufferWork[5]),  
    bExecute    := bExecute  
);  
fbSdoWriteWorkW(  
    sNetId      := sNetId,  
    nSlaveAddr  := nSlaveAddr,  
    nIndex      := 16#5000,  
    nSubIndex   := 6,  
    pSrcBuf     := ADR(bufferWork[6]),  
    cbBufLen    := SIZEOF(bufferWork[6]),  
    bExecute    := bExecute  
);
```

```
IF NOT fbSdoWriteWorkX.bBusy AND NOT fbSdoWriteWorkY.bBusy AND NOT  
fbSdoWriteWorkZ.bBusy AND NOT fbSdoWriteWorkU.bBusy AND NOT fbSdoWriteWorkV.bBusy AND NOT  
fbSdoWriteWorkW.bBusy THEN
```

```
    IF NOT (fbSdoWriteWorkX.bError OR fbSdoWriteWorkY.bError OR  
fbSdoWriteWorkZ.bError OR fbSdoWriteWorkU.bError OR fbSdoWriteWorkV.bError OR  
fbSdoWriteWorkW.bError) THEN
```

```
        (* write successful *)  
        bError := FALSE;  
        nErrorId := 0;  
        nState:= 40;
```

```
    ELSE
```

```
        (* write failed *)  
        bError := TRUE;  
        IF fbSdoWriteWorkX.bError THEN  
            nErrorId := fbSdoWriteWorkX.nErrId;  
        ELSIF fbSdoWriteWorkY.bError THEN  
            nErrorId := fbSdoWriteWorkY.nErrId;  
        ELSIF fbSdoWriteWorkZ.bError THEN  
            nErrorId := fbSdoWriteWorkZ.nErrId;  
        ELSIF fbSdoWriteWorkU.bError THEN  
            nErrorId := fbSdoWriteWorkU.nErrId;  
        ELSIF fbSdoWriteWorkV.bError THEN  
            nErrorId := fbSdoWriteWorkV.nErrId;  
        ELSIF fbSdoWriteWorkW.bError THEN  
            nErrorId := fbSdoWriteWorkW.nErrId;  
        END_IF  
        nState := 9999;
```

```
    END_IF
```

```
    fbSdoWriteWorkX(bExecute := FALSE);
```

```
        fbSdoWriteWorkY(bExecute := FALSE);
        fbSdoWriteWorkZ(bExecute := FALSE);
        fbSdoWriteWorkU(bExecute := FALSE);
        fbSdoWriteWorkV(bExecute := FALSE);
        fbSdoWriteWorkW(bExecute := FALSE);
    END_IF

40:
    (* write Tool coordinate system to SDOs *)
    fbSdoWriteToolX(
        sNetId      := sNetId,
        nSlaveAddr  := nSlaveAddr,
        nIndex      := 16#5001,
        nSubIndex   := 1,
        pSrcBuf     := ADR(bufferTool[1]),
        cbBufLen    := SIZEOF(bufferTool[1]),
        bExecute    := bExecute
    );
    fbSdoWriteToolY(
        sNetId      := sNetId,
        nSlaveAddr  := nSlaveAddr,
        nIndex      := 16#5001,
        nSubIndex   := 2,
        pSrcBuf     := ADR(bufferTool[2]),
        cbBufLen    := SIZEOF(bufferTool[2]),
        bExecute    := bExecute
    );
    fbSdoWriteToolZ(
        sNetId      := sNetId,
        nSlaveAddr  := nSlaveAddr,
        nIndex      := 16#5001,
        nSubIndex   := 3,
        pSrcBuf     := ADR(bufferTool[3]),
        cbBufLen    := SIZEOF(bufferTool[3]),
        bExecute    := bExecute
    );
    fbSdoWriteToolU(
        sNetId      := sNetId,
        nSlaveAddr  := nSlaveAddr,
        nIndex      := 16#5001,
        nSubIndex   := 4,
        pSrcBuf     := ADR(bufferTool[4]),
        cbBufLen    := SIZEOF(bufferTool[4]),
        bExecute    := bExecute
    );
    fbSdoWriteToolV(
        sNetId      := sNetId,
        nSlaveAddr  := nSlaveAddr,
        nIndex      := 16#5001,
        nSubIndex   := 5,
        pSrcBuf     := ADR(bufferTool[5]),
        cbBufLen    := SIZEOF(bufferTool[5]),
        bExecute    := bExecute
    );
    fbSdoWriteToolW(
        sNetId      := sNetId,
        nSlaveAddr  := nSlaveAddr,
        nIndex      := 16#5001,
```



```

        nSubIndex    := 6,
        pSrcBuf      := ADR(bufferTool[6]),
        cbBufLen     := SIZEOF(bufferTool[6]),
        bExecute     := bExecute
    );

    IF NOT fbSdoWriteToolX.bBusy AND NOT fbSdoWriteToolY.bBusy AND NOT
fbSdoWriteToolZ.bBusy AND NOT fbSdoWriteToolU.bBusy AND NOT fbSdoWriteToolV.bBusy AND NOT
fbSdoWriteToolW.bBusy THEN
        IF NOT (fbSdoWriteToolX.bError OR fbSdoWriteToolY.bError OR
fbSdoWriteToolZ.bError OR fbSdoWriteToolU.bError OR fbSdoWriteToolV.bError OR
fbSdoWriteToolW.bError) THEN
            (* write successful *)
            bError := FALSE;
            nErrorId := 0;
            nState:= 50;
        ELSE
            (* write failed *)
            bError := TRUE;
            IF fbSdoWriteToolX.bError THEN
                nErrorId := fbSdoWriteToolX.nErrId;
            ELSIF fbSdoWriteToolY.bError THEN
                nErrorId := fbSdoWriteToolY.nErrId;
            ELSIF fbSdoWriteToolZ.bError THEN
                nErrorId := fbSdoWriteToolZ.nErrId;
            ELSIF fbSdoWriteToolU.bError THEN
                nErrorId := fbSdoWriteToolU.nErrId;
            ELSIF fbSdoWriteToolV.bError THEN
                nErrorId := fbSdoWriteToolV.nErrId;
            ELSIF fbSdoWriteToolW.bError THEN
                nErrorId := fbSdoWriteToolW.nErrId;
            END_IF
            nState := 9999;
        END_IF

        fbSdoWriteToolX(bExecute := FALSE);
        fbSdoWriteToolY(bExecute := FALSE);
        fbSdoWriteToolZ(bExecute := FALSE);
        fbSdoWriteToolU(bExecute := FALSE);
        fbSdoWriteToolV(bExecute := FALSE);
        fbSdoWriteToolW(bExecute := FALSE);
    END_IF

50:
    (* write handshake for Work CS to SDOs *)
    nHsk := 1;

    fbSdoWriteHsk(
        sNetId      := sNetId,
        nSlaveAddr  := nSlaveAddr,
        nIndex      := 16#5010,
        nSubIndex   := 1,
        pSrcBuf     := ADR(nHsk),
        cbBufLen    := SIZEOF(nHsk),
        bExecute    := bExecute
    );
```

```
IF NOT fbSdoWriteHsk.bBusy THEN
    IF NOT fbSdoWriteHsk.bError THEN
        (* write successful *)
        bError := FALSE;
        nErrorId := 0;
        nState:= 60;

    ELSE
        (* write failed *)
        bError := TRUE;
        IF fbSdoWriteHsk.bError THEN
            nErrorId := fbSdoWriteHsk.nErrId;
        END_IF
        nState := 9999;

    END_IF

    fbSdoWriteHsk(bExecute := FALSE);
END_IF

60:
(* write handshake for Tool CS to SDOs *)
nHsk := 1;

fbSdoWriteHsk(
    sNetId      := sNetId,
    nSlaveAddr  := nSlaveAddr,
    nIndex      := 16#5010,
    nSubIndex   := 2,
    pSrcBuf     := ADR(nHsk),
    cbBufLen    := SIZEOF(nHsk),
    bExecute    := bExecute
);

IF NOT fbSdoWriteHsk.bBusy THEN
    IF NOT fbSdoWriteHsk.bError THEN
        (* write successful *)
        bError := FALSE;
        nErrorId := 0;
        nState:= 70;

    ELSE
        (* write failed *)
        nState := 9999;

    END_IF

    fbSdoWriteHsk(bExecute := FALSE);
END_IF

70:
(* wait for click, slave controller needs some time to finish internal calculations
*)
fbTimer1.IN := TRUE;
IF fbTimer1.Q THEN
    nState := 80;
    fbTimer1.IN := FALSE;
END_IF

80:
(* set position to new actual position *)
fbSetPos.PosX := stPIHexapod.stX.NcToPlc.ActPos;
```

```
fbSetPos.PosY := stPIHexapod.stY.NcToPlc.ActPos;
fbSetPos.PosZ := stPIHexapod.stZ.NcToPlc.ActPos;
fbSetPos.PosU := stPIHexapod.stU.NcToPlc.ActPos;
fbSetPos.PosV := stPIHexapod.stV.NcToPlc.ActPos;
fbSetPos.PosW := stPIHexapod.stW.NcToPlc.ActPos;
fbSetPos.bClearPositionLag := TRUE;
fbSetPos.Execute := TRUE;

IF (fbSetPos.bDone) THEN
    fbSetPos.Execute := FALSE;
    nState := 90;
END_IF

90:
    (* set Mode of Operation to 8 and wait until Mode of Operation Display switches to 8
    *)
    stPIHexapod.nModeOfOperation := 8;
    IF stPIHexapod.nModeOfOperationDisplay = 8 THEN
        nState := 100;
    END_IF

100:
    bBusy := FALSE;
    IF NOT bExecute THEN
        nState := 0;
        bDone := FALSE;
    ELSE
        bDone := TRUE;
    END_IF

9999:
    (* an error occurred *)
    bError := TRUE;
    IF fbSdoWriteHsk.bError THEN
        nErrorId := fbSdoWriteHsk.nErrId;
    END_IF

END_CASE

fbSetPos (stPIHexapod := stPIHexapod);
fbTimer1();
```

- Create a new PLC function block (Add -> POU...) named “FB_SetPosHexapod” and copy the following variables to its window for the local variables:

```
FUNCTION_BLOCK FB_SetPosHexapod
VAR_IN_OUT
    stPIHexapod          : ST_PIHexapod;
END_VAR
VAR_INPUT
    Execute              : BOOL := FALSE;
    PosX                  : LREAL := 0.0;
    PosY                  : LREAL := 0.0;
    PosZ                  : LREAL := 0.0;
    PosU                  : LREAL := 0.0;
    PosV                  : LREAL := 0.0;
```

```
PosW          : LREAL := 0.0;
bClearPositionLag : BOOL := TRUE;
END_VAR
VAR_OUTPUT
    bDone          : BOOL := FALSE;
    bError         : BOOL := FALSE;
    nErrorId       : UDINT := 0;
END_VAR
VAR
    fbSetPosX      : MC_SetPosition;
    fbSetPosY      : MC_SetPosition;
    fbSetPosZ      : MC_SetPosition;
    fbSetPosU      : MC_SetPosition;
    fbSetPosV      : MC_SetPosition;
    fbSetPosW      : MC_SetPosition;
END_VAR
```

- And copy the following code to the “FB_SetPosHexapod” function block:

```
(* ToDo: extend error handling *)
(* Set position for all hexapod axes to 0.0 *)

fbSetPosX.Options.ClearPositionLag:= bClearPositionLag;
fbSetPosY.Options.ClearPositionLag:= bClearPositionLag;
fbSetPosZ.Options.ClearPositionLag:= bClearPositionLag;
fbSetPosU.Options.ClearPositionLag:= bClearPositionLag;
fbSetPosV.Options.ClearPositionLag:= bClearPositionLag;
fbSetPosW.Options.ClearPositionLag:= bClearPositionLag;

fbSetPosX(
    Axis:= stPIHexapod.stX ,
    Position:= PosX ,
    Mode:= FALSE,
    Execute:= Execute,
    Busy=> ,
    Done=> ,
    Error=> ,
    ErrorID=> );

fbSetPosY(
    Axis:= stPIHexapod.stY ,
    Position:= PosY ,
    Mode:= FALSE,
    Execute:= Execute,
    Busy=> ,
    Done=> ,
    Error=> ,
    ErrorID=> );


fbSetPosZ(
    Axis:= stPIHexapod.stZ ,
    Position:= PosZ ,
    Mode:= FALSE,
    Execute:= Execute,
    Busy=> ,
    Done=> ,
    Error=> ,
    ErrorID=> );
```

```
fbSetPosU(  
    Axis:= stPIHexapod.stU ,  
    Position:= PosU ,  
    Mode:= FALSE,  
    Execute:= Execute,  
    Busy=> ,  
    Done=> ,  
    Error=> ,  
    ErrorID=> );  
fbSetPosV(  
    Axis:= stPIHexapod.stV ,  
    Position:= PosV ,  
    Mode:= FALSE,  
    Execute:= Execute,  
    Busy=> ,  
    Done=> ,  
    Error=> ,  
    ErrorID=> );  
fbSetPosW(  
    Axis:= stPIHexapod.stW ,  
    Position:= PosW ,  
    Mode:= FALSE,  
    Execute:= Execute,  
    Busy=> ,  
    Done=> ,  
    Error=> ,  
    ErrorID=> );  
  
IF fbSetPosX.Error THEN  
    bError := TRUE;  
    nErrorId := fbSetPosX.ErrorID;  
ELSE  
    IF fbSetPosX.Done AND fbSetPosY.Done AND fbSetPosZ.Done AND fbSetPosU.Done AND  
fbSetPosV.Done AND fbSetPosW.Done THEN  
        bDone := TRUE;  
    ELSE  
        bDone := FALSE;  
    END_IF  
END_IF
```


The final PLC structure should look like this:

User Manual

A000T0075, valid for C-887 controller with EtherCAT interface
FRIE, SSc, BRo, 2/24/2020




- Build the PLC project once to make the new variables visible (a task configuration will be created automatically).




User Manual


A000T0075, valid for C-887 controller with EtherCAT interface
FRIE, SSc, BRo, 2/24/2020

- Link MOTION axis to the corresponding PLC axis reference. Do this for each axis:



- Link the nModeOfOperationDisplay variable to Modes of operation display of Module 1:
PLC -> PIHexapodNewCS -> PIHexapodNewCS Instance -> Main.stPIHexapod.nModeOfOperationDisplay







User Manual

A000T0075, valid for C-887 controller with EtherCAT interface
FRIE, SSc, BRo, 2/24/2020

- Link the ModeOfOperation variable to Modes of operations of Module 1:
PLC -> PIHexapodNewCS -> PIHexapodNewCS Instance -> Main.stPIHexapod.nModeOfOperation



User Manual



A000T0075, valid for C-887 controller with EtherCAT interface
FRIE, SSc, BRo, 2/24/2020

- Link the nStatusWord variable (additionally to nState1 and nState2) to Statusword of Module 1:
PLC -> PIHexapodNewCS -> PIHexapodNewCS Instance -> Main.stPIHexapod. nStatusWord
- Finally the links for the Input variables should look like this:

	Name	Type	Size [Byte]	Linked to
Axis X	Statusword	UINT	2	MAIN.stPIHexapod.nStatusWord, nState1, nState2
	Modes of operation display	BYTE	1	MAIN.stPIHexapod.nModeOfOperationDisplay . PlcTask Inputs . PIHexapodNewCS Instance . PIHexapodNewCS
	Position actual value	DINT	4	nDataIn1 . In . Inputs . Enc . Axis X . Axis X . Axes . NC-Task 1 SAF
	Following error actual value	DINT	4	nDataIn1 . In . Inputs . Drive . Axis X . Axis X . Axes . NC-Task 1 SAF
Axis Y	Statusword	UINT	2	nState1, nState2
	Modes of operation display	BYTE	1	
	Position actual value	DINT	4	nDataIn1 . In . Inputs . Enc . Axis Y . Axis Y . Axes . NC-Task 1 SAF
	Following error actual value	DINT	4	nDataIn1 . In . Inputs . Drive . Axis Y . Axis Y . Axes . NC-Task 1 SAF
Axis Z	Statusword	UINT	2	nState1, nState2
	Modes of operation display	BYTE	1	
	Position actual value	DINT	4	nDataIn1 . In . Inputs . Enc . Axis Z . Axis Z . Axes . NC-Task 1 SAF
	Following error actual value	DINT	4	nDataIn1 . In . Inputs . Drive . Axis Z . Axis Z . Axes . NC-Task 1 SAF
Axis U	Statusword	UINT	2	nState1, nState2
	Modes of operation display	BYTE	1	
	Position actual value	DINT	4	nDataIn1 . In . Inputs . Enc . Axis U . Axis U . Axes . NC-Task 1 SAF
	Following error actual value	DINT	4	nDataIn1 . In . Inputs . Drive . Axis U . Axis U . Axes . NC-Task 1 SAF
Axis V	Statusword	UINT	2	nState1, nState2
	Modes of operation display	BYTE	1	
	Position actual value	DINT	4	nDataIn1 . In . Inputs . Enc . Axis V . Axis V . Axes . NC-Task 1 SAF
	Following error actual value	DINT	4	nDataIn1 . In . Inputs . Drive . Axis V . Axis V . Axes . NC-Task 1 SAF
Axis W	Statusword	UINT	2	nState1, nState2
	Modes of operation display	BYTE	1	
	Position actual value	DINT	4	nDataIn1 . In . Inputs . Enc . Axis W . Axis W . Axes . NC-Task 1 SAF
	Following error actual value	DINT	4	nDataIn1 . In . Inputs . Drive . Axis W . Axis W . Axes . NC-Task 1 SAF
linked automatically by TwinCAT	WcStateOut	BIT	0.1	
	WcStateIn	BIT	0.1	nState4, nState4
	InputToggle	BIT	0.1	nState4, nState4
	State	UINT	2	
	AdsAddr	AMSADDR	8	
	Chn0	USINT	1	
	DcOutputShift	DINT	4	nDcOutputTime . In . Inputs . Drive . Axis 6 . Axis 6 . Axes . NC-Task 1 SAF
	DcInputShift	DINT	4	nDcInputTime . In . Inputs . Enc . Axis 6 . Axis 6 . Axes . NC-Task 1 SAF

- Finally the links for the Output variables should look like this:

Axis X	Controlword	UINT	2	nCtrl1, nCtrl2
	Modes of operation	BYTE	1	MAIN.stPIHexapod.nModeOfOperation . PlcTask Outputs . PIHexapodNewCS Instance . PIHexapodNewCS
	Target position	DINT	4	nDataOut1 . Out . Outputs . Drive . Axis X . Axis X . Axes . NC-Task 1 SAF
Axis Y	Controlword	UINT	2	nCtrl1, nCtrl2
	Modes of operation	BYTE	1	
	Target position	DINT	4	nDataOut1 . Out . Outputs . Drive . Axis Y . Axis Y . Axes . NC-Task 1 SAF
Axis Z	Controlword	UINT	2	nCtrl1, nCtrl2
	Modes of operation	BYTE	1	
	Target position	DINT	4	nDataOut1 . Out . Outputs . Drive . Axis Z . Axis Z . Axes . NC-Task 1 SAF
Axis U	Controlword	UINT	2	nCtrl1, nCtrl2
	Modes of operation	BYTE	1	
	Target position	DINT	4	nDataOut1 . Out . Outputs . Drive . Axis U . Axis U . Axes . NC-Task 1 SAF
Axis V	Controlword	UINT	2	nCtrl1, nCtrl2
	Modes of operation	BYTE	1	
	Target position	DINT	4	nDataOut1 . Out . Outputs . Drive . Axis V . Axis V . Axes . NC-Task 1 SAF
Axis W	Controlword	UINT	2	nCtrl1, nCtrl2
	Modes of operation	BYTE	1	
	Target position	DINT	4	nDataOut1 . Out . Outputs . Drive . Axis W . Axis W . Axes . NC-Task 1 SAF