

E-515

Display Modules for Modular Piezo Controllers

>> Click <http://www.pi.ws/fwd/Piezo-Driver> for the Latest Specs on these Products



Ordering Information

E-515.01
Display Module for PZT Voltage/Displacement

E-515.03
Display Module for PZT Voltage/Displacement, 3 Channels

Ask about custom designs!

- 3 1/2-digit LED Display
- For Voltage & Displacement Data
- 1- & 3-Channel Versions

The E-515.01 and E-515.03 are one and three channel display modules for PZT voltage and displacement data. Toggle switches for each channel select voltage or displacement mode. The voltage/displacement range for each channel is internally set by jumpers and trimmers.

Notes
E-515 is not a stand-alone device. It is designed to work in the E-500/E-501 chassis (p. 6-18), the E-471 or the E-480 amplifier (p. 6-48, p. 6-50) with integrated power supply.

Technical Data

Models	E-515.01	E-515.03
Function	Display for voltage & displacement	Display for voltage & displacement
Channels	1	3
Linearity	0.1 %	0.1 %
Display	1 x 3 1/2-digits	3 x 3 1/2-digits
Dimensions	One 21T slot wide, 3H high	One 21T slot wide, 3H high
Weight	0.3 kg	0.3 kg
Operating voltage	Requires E-530/E-531 power supply (E-500/E-501 system, etc.)	Requires E-530/E-531 power supply (E-500/E-501 system, etc.)